

Trailer Types and Definitions

Heavy Vehicle Registration Assessment Scheme (HVRAS)

Trailers over 750kgs aggregate trailer mass (ATM) must be inspected by a HVRAS accredited person, or at a Department of Transport and Main Roads (TMR) transport and motoring service centre, prior to registration in Queensland. The table below provides a definition of the various trailers and the corresponding inspection sheet for each trailer type.

Not all TMR locations have the capacity to conduct inspections. To confirm if a location can inspect trailers, refer to https://www.qld.gov.au/transport/contacts/centres for the list of services provided by location.

Box (Pig) Trailer Form F3123 to be completed	Pig trailer means a trailer: with one axle group or a single axle near the middle of its load carrying surface; and connected to the towing vehicle by a drawbar.	
Dog Trailer Form F3148 to be completed	Dog trailer means a trailer (including a trailer consisting of a semitrailer and converter dolly) that has: • one axle group or a single axle at the front that is being steered by connection to a towing vehicle by a drawbar; and • one axle group or a single axle at the rear.	
Semi-Trailer Form F3128 to be completed	 Semi-Trailer means a trailer that has: one axle group or a single axle towards the rear; and a means of attachment to a prime mover that results in some of the mass of the trailer's load being imposed on the prime mover. 	



	-	
Lead/Middle Trailer Form F3128 to be completed	A semi-trailer with a turntable mounted over the axle group at the rear of a trailer.	
Converter Dolly Trailer Form F3646 to be completed	a pig trailer with a fifth wheel coupling designed to convert a semi-trailer into a dog trailer.	
Low Loader Dolly Form F3154 to be completed	Low loader dolly means a device for distributing mass that: • is usually coupled between a prime mover and low loader; and • consists of a rigid frame of a gooseneck shape; and • does not directly carry any load; and • is equipped with one or more axles, a kingpin and a fifth wheel coupling.	
Low Loader Trailer Form F3154 to be completed	a trailer with a loading deck no more than 1m above the ground.	
Tag Trailer Form F3128 to be completed	 Tag trailer means a trailer: with one axle group or a single axle towards the rear of its load-carrying surface; and connected to a towing vehicle by a drawbar. 	

Caravan

A caravan means:

Form F3123 to be completed

 an enclosed trailer designed for people to live in (includes camper trailers).

*See note below



Mobile Equipment Trailer or Mobile Machinery Trailer (NonLoad Carrying)

Form F3123 to be completed

Mobile equipment/mobile machinery trailer:

- has equipment permanently attached that perform specific tasks.
- are not able to carry a load with the exception of any auxiliary equipment for performing the function for which they are designed.
- must be registered with a registration category of STRL e.g. a compressor trailer.
- requires a weighbridge certificate/supervised weigh documentation.



*Note: A caravan or camper trailer must be equipped with cooking facilities, living or sleeping accommodation. A caravan or camper trailer (including pop-top camper trailer) must have only outward-opening or sliding doors. At least one such door must be located on the left-hand side or at the rear. There is no requirement for doors on trailer-based fold out campers.

A caravan or camper trailer designed primarily for human occupation whilst stationary, must be fitted with a fire extinguisher. When conducting an inspection on a caravan or camper trailer it is not a requirement to check the safety or validity of the fire extinguisher.

Contact us

Phone	13 23 80 (ask for the HVRAS Administrator) 13 23 80 (ask for the Light Vehicle Standards Help Desk) 1300 696 487 (ask for the Heavy Vehicle Standards Team)
Email	hvras@tmr.qld.gov.au (preferred contact method) vehiclestandards@tmr.qld.gov.au (light vehicle preferred contact method)
	<u>vehiclestandards@nhvr.gov.au</u> (heavy vehicle preferred contact method)
Website	www.tmr.qld.gov.au/hvras www.tmr.qld.gov.au/vehiclestandards www.nhvr.gov.au/vehiclestandards
Post	HVRAS Administrator Department of Transport and Main Roads PO Box 673 Fortitude Valley Qld 4006